



# Liveo™ MG 7-9900 Soft Skin Adhesive Kit (A & B)

## Silicone Adhesives

Soft elastomeric silicone adhesive for adhering medical devices to the skin with medium adhesion force and gentle removal.

### Composition

Two-part platinum catalyzed, fillerless, elastomeric silicone adhesive

### Applications:

Liveo™ MG 7-9900 Soft Skin Adhesive is intended for medical device applications that require medium adhesion to the skin with gentle removal, including over-the-counter bandages, scar therapies and advanced wound care dressings.

### Features

- Transparent before and after curing
- Platinum-catalyzed cure
- No cure by-products
- Solvent-less
- Two parts with similar viscosities and 1:1 mixing ratio
- Low viscosity before curing

### Benefits

- Biocompatible
- Tacky
- Medium adhesion to the skin
- Gentle removal from skin
- No residue upon removal
- Repositionable
- Low peel release force from polyethylene and polypropylene liners
- Easily processable two-parts system
- Adjustable adhesion force level depending on adhesive coat weight

### Regulatory & Biocompatibility information

Product Regulatory Information document as well as Summary of health data are available from our DuPont website or upon request.

### Packaging

These products are supplied in 30 kg pail, 320 kg drum or 1900 kg tote size kits. Samples are available in 908 g kits. Each kit contains equal portions of Part A and Part B.



# Liveo™ MG 7-9900 Soft Skin Adhesive Kit (A & B)

## Silicone Adhesives

### Quality information

The FDA registered and ISO 9001:2015 certified Healthcare Industries Materials Site (HIMS site) is responsible for ensuring consistent product quality.

### Rheological properties

Viscosity, component A	5 Pa.s
Viscosity, component B	5 Pa.s

### Application technique

Pot life	20 min
----------	--------

### Cured properties

Penetration after cure, 62.5g cone	140 mm/10
Release, polyethylene	0.05 N/2.5cm
Adhesion, polycarbonate	1.9 N/2.5cm

### Storage and stability

Shelf life	12 <sup>1</sup> months
------------	------------------------

1: when stored at or below room temperature in the original unopened containers

### Characteristics

Compatibility	Polyurethane, Silicones
---------------	-------------------------

### Additional Information

How to use

#### Mixing:

Thoroughly mix the desired amount part A and part B in a 1:1 ratio by weight. Static mixers are recommended mixing tools. During mixing, care should be taken to minimize air entrapment. Airless mixing, metering and dispensing equipment is recommended for large production processing.

#### De-airing:

If a void-free finished part is desired, the entrapped air must be removed from the mixed materials. Exposure to a residual pressure of 711 Torr for several minutes is typically adequate. The vessel containing the material should be at least four times the volume of the mixture to allow for expansion.

#### Coating:

The suggested coating method is knife over roll. Suggested coating thickness is from 0.1mm to 0.5mm (approximately 100g/m<sup>2</sup>-500g/m<sup>2</sup>). Thicker coats can be applied if more elastomeric properties are desired.

#### Curing:

The cure reaction will begin once the two parts have been mixed. The initial



# Liveo™ MG 7-9900 Soft Skin Adhesive Kit (A & B)

## Silicone Adhesives

viscosity will at least double within 20 minutes at 25°C. The cure reaction will occur at room temperature; however heating will accelerate the process.

### Cleaning:

To remove uncured adhesive, Liveo™ Q7-9180 (0.65cst) Silicone Fluid, isopropyl alcohol, ethyl acetate, xylene or heptane can be used. When the adhesive is cured, the greater part should be removed by mechanical means and only the remaining material should be removed with one of the aforementioned solvents.

### Safety Warning

Before handling, please consult the corresponding material safety data sheets. These are available upon request or can be downloaded from our DuPont website :

## Chemical Media Resistance

### Sterilisation methods

- ✓ Ethylene Oxide

### Symbols used:

- ✓ possibly resistant  
Defined as: Supplier has sufficient indication that contact with chemical can be potentially accepted under the intended use conditions and expected service life. Criteria for assessment have to be indicated (e.g. surface aspect, volume change, property change).
- ✗ not recommended - see explanation  
Defined as: Not recommended for general use. However, short-term exposure under certain restricted conditions could be acceptable (e.g. fast cleaning with thorough rinsing, spills, wiping, vapor exposure).

The information set forth herein is furnished free of charge, is based on technical data that DuPont believes to be reliable, and represents typical values that fall within the normal range of properties. This information relates only to the specific material designated and may not be valid for such material used in combination with other materials or in other processes. It is intended for use by persons having technical skill, at their own discretion and risk. This information should not be used to establish specification limits nor used alone as the basis of design. Handling precaution information is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards and comply with applicable law. Since conditions of product use and disposal are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any product, evaluation under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate or a recommendation to infringe on patents.

CAUTION: Do not use DuPont materials in medical applications involving implantation in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract or other acknowledgement that is consistent with the DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative.

DuPont's sole warranty is that our products will meet our standard sales specifications in effect at the time of shipment. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, DUPONT SPECIFICALLY DISCLAIMS ANY OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR NON-INFRINGEMENT. DUPONT DISCLAIMS LIABILITY FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.